


**AIRPET - Regional Air Pollution
Research Program
Phase 1: 2001-2003
Sponsored by Sida/SAREC**

<http://www.serd.ait.ac.th/airpet/>



Dr. Kim Oanh N. T.
EEM, SERD, AIT
Bangkok, Thailand

Project Team



China

Prof. Hao Zhengping
Research Center for Eco-
Environmental Sciences
18 Shuangqing Road
PO Box 2871, Beijing 100085,
CHINA



Vietnam

Dr. Hoang Xuan Co
Faculty of Environmental
Sciences
Hanoi University of Science
334 Nguyen Trai Road
Thanh Xuan, Hanoi
VIETNAM



India

Prof. DVS Murthy
Environmental Eng. Lab
Dept. of Chemical Eng.
I.I.T. Madras, Chennai 600036
INDIA



Philippines

Dr. Jose Villarin
Climate Studies Division
Manila Observatory
PO Box 122, U.P. Post Office
1101 Quezon City
PHILIPPINES





Indonesia

Dr. Ir. Puji Lestari
Environmental Engineering
Department
Institut Teknologi Bandung
Jl. Ganesha No. 10
Bandung – 40132
INDONESIA



Project team


Sponsored by Sida




Improving Air Quality in Asian Developing Countries

Project goal: mobilize and enhance capacity in the involved countries

- To establish comprehensive assessment of air pollution status
- To develop suitable control technologies
- To apply modeling tools for integrated air quality management




Activities – Outputs



Phase 1 Planned Activities

Jan. 2001- Dec. 2003

NRIs	Monitoring	Control	Modeling	
			Receptor	Disp.
AIT	X	X	X	X
China	X	X	X	
India	X	X	X	
Indonesia	X	X	X	
Philippines	X		X	X
Vietnam	X		X	X




Monitoring: major issue

Designed Monitoring Program for Consistency and Uniformity


- Site selections:
 - 5 types: traffic, industrial, residential/mixed, commercial site and background
 - One site for each type
- Monitoring period/times: dry and wet seasons
- Sampling equipment for PM10 & PM2.5: dichot, available equipment to be evaluated against dichot
- Analytical methods: existing equipment and standard QA/QC: SRM, blanks & blind samples

Source apportionment of PM10, PM2.5 by receptor modeling



Objectives: to quantify source contributions by sector so that appropriate policies can be drafted


Receptor modeling



Measurement for PM, VOC at a receptor

Find main contributors to C: focus mitigation efforts

Receptor Model Complements Dispersion Model to Understand Source-Receptor Relationship



Receptor Modeling for Source Apportionment


- Quantify contributions to $PM_{2.5}$, PM_{10} , VOC, etc.
- Improve emissions inventories
- Verify source dispersion models
- Formulate conceptual models of source receptor relationships



Conceptual Receptor Model

- Describes the relevant physical and chemical processes
- Identifies potential sources of primary emissions
- Documents potential for secondary aerosol formation

Receptor models





Some Receptor Models

- Chemical Mass Balance
- Temporal and spatial correlation eigenvectors (e.g., PCA, FA)
- Multiple linear regression (MLR)
- Neural networks
- Time series (e.g., spectral analysis etc.)

Common Mathematical Formula for Receptor Modeling

The concentration of a pollutant at a receptor site is the sum of linear products of the source profile and the source strength

$$x_{ij} \approx \sum_k a_{ik} f_{kj}$$

Solve Equation
for f_{kj}

x_{ij} = Concentration of species i in the sample j

a_{ik} = Source profiles (fraction of i in k source)

f_{kj} = Source strength or contribution of k^{th} source to j^{th} sample (unknown)



Example: CMB application


- Simple Example:
 - Pb in an ambient sample: $X_{ij} = 1.0 \text{ ug/m}^3$
 - a_{ik} in Auto Exhaust = 20% = 0.2
- Contribution of Auto Exhaust is 5 ug/m^3
- Assumption: Autos are only source of Pb

Receptor Model Needs



- Source properties that identify and quantify source contributions at a receptor (source profiles)
- Measurements at receptor to better distinguish among sources
 - Sampling locations, periods and durations; particle sizes; precursor gases; and chemical and physical components

Source Profiles






Chemical analysis of PM

- Speciation
 - Carbon – EC/OC/BC
 - Trace Elements
 - Ionic Species
 - Sulfate
 - Nitrate
 - Ammonium
 - Hydrocarbons

Analysis for PM chemical composition

Elements	Analytical equipment	Notes
Metals	AAS, ICP/MS, ICP/AES, INAA (upto 40 elements)	Sample destruction
	XRF & PIXE: ~ 25 elements with atomic No. 11-92	No destruction
OC, EC	Thermal combustion, Optical absorption, TMO, etc.	Operational definitions
BC (light abs.C)	Reflectormeter	No destruction
Carbonate Carbon	Acidification of filter at room temperature	Destruction
Ions	AAS: single ions (Na, Mg, K, Ca) IC: polyatomic ions (SO_4^- , NO_3^- , ...)	destruction

Black carbon measurements (AIT)




The standardized reflectormeter gives measurements which are converted to mass of BC using a formula

Number of samples required for receptor modeling

- CMB: in principle can run with 1 sample
- Statistical models (PMF) need more samples
$$N > 30 + (V + 3)/2$$

V: variables - No. of species measured (or source emission tracers), normally $V = 20 \Rightarrow N_{\min} = 42$
- AIRPET focus:
 - Mixed site and background site: to have enough samples to run both models
 - Other sites: min 10-15 samples to run CMB8

Multicollinearity in source apportionment

- 
- Nature of problem: 2 or more sources have very similar signatures. More generally, problem exists when one source signature is nearly a linear combination of any subset of the other signatures → can not identify these sources
 - Symptoms of CMB results:
 - Large negative aerosol contributions from these source types
 - Estimated uncertainties are larger than the calculated source contributions themselves



Dealing with Multicollinearity

- Identify multicol. by physical & chemical judgement
 - Eliminate a source if strong physical evidence exists such as downwind sources during strong wind
 - Source selection: manual examination of source signatures and group sources with similar signatures (soil, road dust) => reduces resolution of apportionment
- Statistical measures to identify multicol. involving several sources:
 - VIF (variance inflation factor) is measure of multicol. VIF is the increase in error variance of the estimated aerosol contribution of a specific source due to multicol. alone
 - Use special statistical technique (ridge regression, regression on PCA)

Uncertainties of data




- Uncertainty of average source profiles: 2 approaches (Henry, 1982)
- Uncertainty of ambient data (for CMB8): standard deviation of the analytical methods, both gravimetric and chemical analysis → for determination repeat analysis for the same sample and determine SD → uncertainty of sampling?



Results of PM Apportionment for Bangkok Metropolitan Region

- Sampling equipment: Dichot
 - PM2.5 and PM10-2.5
- Source profiles: from literature some available for BMR
- Sample analysis: Mass, BC, 29 elements, and 8 ions
- Totally: over 40 parameters



Bangna: urban mixed site (industrial)
 Ban Somdet: urban residential site
 Bangplee: industrial site

Din Daeng: traffic site
 Bangkok Unv: Sub-urban site
 AIT: Upwind background

Dichotomous sampler



Inlet head

Virtual impactor

Filter holders

Coarse low

1.67 l/min


Fine flow

15.03 l/min




Flow control unit

Co-location of dichot and other available samplers




- 2 dichotomous samplers at a site
- PM mass concentration comparability (not always the same)
- Different filter papers used simultaneously for different analyses

Analytical Plan for Receptor Modeling




Variation of PM_{2.5} and PM_{10-2.5}






Source Apportionment by CORPREM for All Samples






COPREM Source Apportionment






COPREM Results: Source Apportionment






CMB Results: Source Apportionment







CMB Results: Source Contribution



Sensitivity of O₃ formation to precursor changes





Original database



Modified database

Impact of Management Strategies on Peak 1-h O_3 in Bangkok





Thank you !